

## BRUSN5 - 0.5 のH寸法指定範囲を修正

型式		No. 選択	H 指定5mm単位	L 指定5mm単位	h
Type	T				
BRUSN	3	0.2	10~50	30~800	3.5
		0.3			
	5	0.2	10~50		5.5
		0.3	10~50		
		0.5	10~50		
BRUSE	3	0.075	10~30		3.5
BRUSM	3	0.3	10~50		3.5
	5				5.5
BRUSK	5	0.6	10~50	5.5	

## &lt;貼り付け用&gt;

型式		No. 選択	H 指定5mm単位	L 指定5mm単位	h	d
Type	T					
BRUSN	3	0.2	10~50	30~800	3.5	0.21
		0.3				0.295
	5	0.2	10~50		5.5	0.21
		0.3	10~50			0.295
		0.5	10~50		0.535	
BRUSE	3	0.075	10~30		3.5	0.075
BRUSM	3	0.3	10~50		3.5	0.3
	5				5.5	
BRUSK	5	0.6	10~50	5.5	0.6	